



## Pressure Vs Torque Conversion Chart

### TPS TS-08 Square Drive Torque Wrench

Pressure	Torque		Pressure	Torque	
Psi	Ft-Lb		Bar	Kgm	Nm
1000	738		69	102	1001
1200	886		83	122	1201
1400	1034		97	143	1402
1600	1173		110	162	1590
1800	1320		124	182	1790
2000	1476		138	204	2001
2200	1613		152	223	2187
2400	1759		166	243	2385
2600	1906		179	264	2584
2800	2053		193	284	2783
3000	2215		207	306	3003
3200	2362		221	327	3202
3400	2510		234	347	3403
3600	2658		248	367	3604
3800	2805		262	388	3803
4000	2953		276	408	4004
4200	3100		290	429	4203
4400	3287		303	454	4457
4600	3437		317	475	4660
4800	3586		331	496	4862
5000	3736		345	517	5065
5200	3885		359	537	5267
5400	4034		372	558	5469
5600	4184		386	578	5673
5800	4333		400	599	5875
6000	4507		414	623	6111
6200	4657		428	644	6314
6400	4808		441	665	6519
6600	4958		455	685	6722
6800	5108		469	706	6926
7000	5258		483	727	7129
7200	5409		497	748	7334
7400	5613		510	776	7610
7600	5765		524	797	7816
7800	5917		538	818	8022
8000	6069		552	839	8228
8200	6220		566	860	8433
8400	6372		579	881	8639
8600	6524		593	902	8845
8800	6675		607	923	9050
9000	6827		621	944	9256
9200	6979		634	965	9462
9400	7131		648	986	9668
9600	7282		662	1007	9873
9800	7434		676	1028	10079
10000	7586		690	1049	10285