



Pressure Vs Torque Conversion Chart

TPS TH-08 Low Profile Torque Wrench

Pressure	Torque		Pressure	Torque	
Psi	Ft-Lb		Bar	Kgm	Nm
1000	740		69	102	1003
1200	888		83	123	1204
1400	1036		97	143	1405
1600	1181		110	163	1601
1800	1327		124	183	1799
2000	1471		138	203	1994
2200	1617		152	224	2192
2400	1770		166	245	2400
2600	1921		179	266	2605
2800	2071		193	286	2808
3000	2220		207	307	3010
3200	2365		221	327	3207
3400	2511		234	347	3404
3600	2654		248	367	3598
3800	2796		262	387	3791
4000	2933		276	406	3977
4200	3076		290	425	4170
4400	3217		303	445	4362
4600	3385		317	468	4589
4800	3542		331	490	4802
5000	3700		345	512	5017
5200	3858		359	533	5231
5400	4006		372	554	5431
5600	4155		386	574	5633
5800	4304		400	595	5835
6000	4473		414	618	6065
6200	4663		428	645	6322
6400	4833		441	668	6553
6600	5001		455	691	6780
6800	5149		469	712	6981
7000	5298		483	732	7183
7200	5443		497	753	7380
7400	5605		510	775	7599
7600	5767		524	797	7819
7800	5940		538	821	8054
8000	6102		552	844	8273
8200	6237		566	862	8456
8400	6381		579	882	8651
8600	6524		593	902	8845
8800	6673		607	923	9047
9000	6829		621	944	9259
9200	6985		634	966	9470
9400	7146		648	988	9689
9600	7298		662	1009	9895
9800	7450		676	1030	10101
10000	7602		690	1051	10307